


## ADEMCO 6152RF Keypad / Transceiver – User Guide

Fixed Addressable Keypad/Transceivers for use with Honeywell Control Panels; incorporates normally-open relay output with the functions of a 16 zone RF Receiver and a 5800 Transmitter module.



### SETTINGS KEY FUNCTION

The Settings key provides an easy method to test the keypad display.

**For Display Test mode:** Press and hold **SETTINGS** for 2 seconds.

### FUNCTION KEYS

The Function keys may be programmed by the installer for special functions or alarm activations. Key pairs may also be programmed for alarm activations.

To activate the Function keys, press and hold the key for at least 2 seconds; key pairs are activated immediately.

A or	1 OFF	and	*
B or	*	and	#
C or	3	and	#
D			

### COMMERCIAL STAY MODES

For commercial controls, if Stay Mode 2 is programmed, refer to the control's manuals and the table below for Stay mode arming.

STAY	+ 1 = Stay Mode 1
STAY	+ 2 = Stay Mode 2
NIGHT	= Stay Mode 3 (both Stay 1 and Stay 2 modes)

**Note:** Not intended for use with the VISTA-128/250 Series. Check with the system installer for more information.

## USER MODE

In the User Mode, individual wireless keys can be enabled and disabled. This is particularly useful if a user loses a wireless key.

**Note:** Only wireless keys programmed directly into the 6152RF can be enabled and disabled using this mode.

Single Button Arming can also be enabled or disabled from the User Mode. See details on the following pages.

### Enter the User Mode

At least 60 seconds after power up, press and hold down the  and  keys at the same time for 3 seconds. The screen flashes "dE" and "-" alternately.

### Enable or Disable Wireless Keys

1. Enter the number of the wireless key transmitter (1-8) to be enabled or disabled. The screen will alternately flash "d" and the wireless key number you entered with "1" or "0" (1 = Enabled, 0 = Disabled).
2. Enter [1] to enable or [0] to disable the wireless key. All wireless keys are defaulted to 1 (enabled).
3. Press  to accept the entry. The screen flashes "dE" and "-" alternately again.
4. Repeat the procedure for all the wireless keys whose status you want to change.
5. Press  when "dE" and "-" are flashing alternately on the screen to move to the User Code entry screen.

## SINGLE BUTTON ARMING

If desired, the Arming Keys can be set for Single Button Arming by following prompts to store a valid user code in the keypad. (See the system User Guide for details on programming user codes.)

### Enabling Single Button Arming

1. The 'User Code' entry screen alternately flashes "u4", "- -" and "- -".
2. Enter a valid four digit user code between 0000 – 9999 and the screen alternately flashes "u4", and the user code you entered, two digits at a time.  
**Recommended:** Set a dedicated user code for this feature.
3. Press  to save the user code and exit User Mode.

**Note:** The user code must be entered for each keypad in the system where Single Button Arming is desired.

### Disabling Single Button Arming

1. Press and hold down the  and  keys at the same time for 3 seconds. The screen displays "dE" and "-" flashing alternately.
2. Press  to move to the 'User Code' entry screen. [The screen alternately flashes "u4", "- -" and "- -".]
3. Enter  and then press  to exit.

When Single Button Arming is disabled, a valid user code is required to arm the system with the Arming keys.

## SOUNDER

- Two-tone sound = burglary and audible panic alarms
- Pulsing sound = fire or carbon monoxide alarms

Refer to the system's user guide for details of audible notifications.

### **FEDERAL COMMUNICATIONS COMMISSION (FCC) STATEMENTS**

The user shall not make any changes or modifications to the equipment unless authorized by the Installation Instructions or User's Manual. Unauthorized changes or modifications could void the user's authority to operate the equipment.

#### **Class B digital device Statement**

This equipment has been tested to FCC requirements and has been found acceptable for use. The FCC requires the following statement for your information:

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- If using an indoor antenna, have a quality outdoor antenna installed.
- Reorient the receiving antenna until interference is reduced or eliminated.
- Move the radio or television receiver away from the receiver/control.
- Move the antenna leads away from any wire runs to the receiver/control.
- Plug the receiver/control into a different outlet so that it and the radio or television receiver are on different branch circuits.
- Consult the dealer or an experienced radio/TV technician for help.

#### **INDUSTRY CANADA CLASS B STATEMENT**

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

#### **FCC / IC STATEMENT**

This device complies with Part 15 of the FCC rules and RSS210 of Industry Canada. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Cet appareil est conforme à la partie 15 des règles de la FCC & de RSS 210 des Industries Canada. Son fonctionnement est soumis aux conditions suivantes: (1) Cet appareil ne doit pas causer d'interférences nuisibles. (2) Cet appareil doit accepter toute interférence reçue y compris les interférences causant une réception indésirable.

REFER TO INSTALLATION INSTRUCTIONS FOR THE CONTROL PANEL WITH WHICH THIS DEVICE IS USED FOR WARRANTY INFORMATION AND LIMITATIONS OF THE ENTIRE ALARM SYSTEM.

**Honeywell**

2 Corporate Center Drive, Suite 100  
P.O. Box 9040, Melville, NY 11747

Copyright © 2013 Honeywell International Inc.  
[www.honeywell.com/security](http://www.honeywell.com/security)



800-11538V1 7/13 Rev A